

movementlock™

adaptations™



Because
you
are not
made to
standard
specifications...

ErgoChair

...neither are
our chairs

movementlock

The Movement Lock™ was developed, 'in-house', by us, in response to customer needs, and has proved to be a popular addition to the Adaptations™ available on the Adapt® ranges.

"The MovementLock works by holding your chair still while you transfer in or out of it. This is particularly useful if you are using a wheelchair, crutches or have other restricted mobility issues"

The Movement Lock uses air-cell technology to move the anti-slip feet downwards to make contact with the floor. The air cell is inflated by means of a battery operated Mini-pump or manual hand pump which can be situated almost anywhere on the chair. An air release button allows the feet to retract and the chair to become mobile once again on the castors. The Movement Lock is fitted with a non-swivel height adjustable gas lift as standard but other gas lifts are available

swivellock

Movement Lock™ Order Code: MLOCK

To compliment the Movement Lock, a 'Swivel Lock' is available, to enable you to choose between a locked and unlocked gas-lift rotation function with one simple lever

Swivellock is available in a 7" or 9" option

Swivellock Order codes: SLOCK7 / SLOCK9



Ergochair

'Movement Lock™ & Swivellock™ are property of Ergochair Ltd and protected by Registration of Design Right. © Ergochair Ltd

Ergochair Ltd
Unit 1, Rainbow Court
Armstrong Way
Yate
Bristol, BS37 5NG

t: 01454 329210
f: 01454 329266
e: sales@ergochair.co.uk
w: www.ergochair.co.uk